# **Printfinish Mini Air Cushion Machine**

### Instruction Manual

Please use the power safely; disconnect the power immediately if abnormality is found. Ensure the earth Wire is connected safely; prohibition of non-standard electricity use.

The Printfinish Air Cushion machine is made of pure high-strength engineering plastics with long service life. It's portable, with a clear operation interface, compatible with different types of inflatable bags. The temperature and air volume speed can be adjusted according to demand.

- Size: 13" x 6.6" x 9.8" (35 x 17 x 25cm)

- Box size: **15.7"x 10.4" x 12"** (40 x 26.5 x 31cm)

- Net weight: 17.6lb (8kg) - Weight: **18.7lb** (8.5kg)

- Input voltage: AC 110-220V

- Rated power: 200W

- Rated frequency: 50HZ/60HZ

- Heal sealing temperature: 1-9 level

- Power connection: Y

- Inflation speed: 6 m/ 16m per minute

- Gas volume: 1-9 level - Anti-shock level: Class I

### Package content

1. Discharge shaft (1)

2. Supporting stick (1)

3. Power cord (1)

4. Hexagonal tools (4)

5. Guide stick (2)

6. Printfinish Air Cushion Machine (1)

### Warning

Please check the following conditions before operation:

1. Ensure the earth Wire is connected safely,

2. Ensure the whole machine is intact and the wire is not exposed,

3. Please carefully watch the machine warnings 4. It is forbidden to open the hack cover and repair it privately.

5. It is forbidden to start the machine when the belt is disconnected.

The set temperature cannot exceed level 4 during summer.

6. For Air Pillow Bubble type, set temperature to level 2-3, air volume level 9. For regular Air Pillow, temperature level 2-3, air volume level 3-4. Please adjust it according to regions.

## Installation and use method

- 1. Connect and turn on the power;
- 2. Insert the roll on the discharge shaft, pass the film through the guide slick and pull it to the belt section:
- 3. Press the feed button, the film needs to be pulled over the other end of the trachea, then press high-speed or low-speed.



### Scan me















